

CATALOGUE 2018

BEST
SELLERS



A Group brand | legrand

INDEX



4	LOADS CONTROL
6	LOCAL MEASUREMENT POINTS
8	ENERGY MONITORING
10	STATIC ENERGY METERS CONTO
12	MULTIFUNCTION METERS NEMO
14	NETWORK ANALYSER NEMO
16	MONITORING SYSTEMS
20	MEASUREMENT AND MANAGEMENT SYSTEM
24	TRANSFORMERS
28	NETWORK PROTECTION
32	DIGITAL INDICATORS
34	ANALOGUE INDICATORS
36	TRANSDUCERS

LOADS CONTROL



Load management relay

Load management relay, for single phase network up to 6 kW.




Beep

Beep is a consumption management relay for single phase networks with users up to 6 kW, designed to solve this problem.

It continuously monitors the power used and, if the power threshold that can be set is exceeded, it emits a warning by means of a buzzer so that the loads can be manually removed in order to reduce the power before the electricity cuts out or, if the relay-type output is enabled, it automatically cuts off the non-priority loads. These are then reactivated after a lapse of time that can be programmed.

Thanks to the programming of the overload threshold (up to 6.5 kW), it can be used on users with different powers 3-4,5-6 kW (default setting per user 3 kW) and it is able to manage non-priority loads up to 16A. During normal functioning, if the front key is pushed, it is possible to display with red LEDs, the real time values of the active power (kW), the voltage (V) and the current (A).

Cat. Nos.	Input	Alarm intervention threshold	Output	Aux
RM2P133	230V - 28A	0...6,5kW	1 (SPST 250Vac-16A)	230Vac



LOCAL MEASUREMENT POINTS



Energy meters

Energy meters for LV single phase 1PH+N show on LCD display the simple count of the active energy consumption (kWh) class 1 EN/IEC 62053-21.



Conto D1 (NT784)

Direct-connected unidirectional energy meter
1 DIN module - 20mA starting current

Cat. Nos.	Current	Voltage	Aux	Output
CE11165A0	up to 32A	230V	Self supplied	-
CE11165A2	up to 32A	230V	Self supplied	Pulse



Conto D2-b (NT660)

Direct-connected unidirectional energy meter
2 DIN modules - 20mA starting current

Cat. Nos.	Current	Voltage	Aux	Output
CE21175A0	up to 32A	230V	Self supplied	-

Multimeters without energy counting

Multimeters with backlit LCD displays for three-phase 3PH/3PH+N in LV with CT connection.

True RMS of: A, V, kW, kvar, kVA, average A, average kW, Hz, $\cos\phi$, h.



NEMO D4-b (NT588)

4 DIN modules

Cat. Nos.	Current	Voltage	Aux	Output
MF6GT00076	from CT /5A	up to 480V	230Vac	-



KIT NEMO D4-b + TAIBB (NT860)

KIT ready for installation, includes 1 multifunction + 3 TAIBB for currents from 60 to 250A
Closed core TAIBB with $\varnothing$ 21mm windows.

Cat. Nos.	Current	Voltage	Aux	Output
K1NEMOD4B060	60A	up to 480V	230Vac	-
K1NEMOD4B100	100A	up to 480V	230Vac	-
K1NEMOD4B150	150A	up to 480V	230Vac	-
K1NEMOD4B250	250A	up to 480V	230Vac	-




NEMO 72-b (NT651)

flush mounting, 72x72mm

Cat. Nos.	Current	Voltage	Aux	Output
MF7GT0009A	from CT/5A	up to 450 V	Self supplied	-
MF7GT2009A	from CT/5A	up to 450 V	Self supplied	2 alarms ¹

¹ individually programmable thresholds for one of the measured variables



ENERGY MONITORING

In the last few years the the increase in energy costs has led to greater attention being paid to consumption and the possibilities of carrying out work to save precious energy.

Effective energy diagnosis showing consumption and pinpointing the possibilities of carrying out work to recover efficiency is essential for energy saving.

The essential element to create it are the collection of the electrical parameter-related data and the transmission to supervision systems for the centralised management and processing of the measurements.


IME offers a complete range of instruments to detect the consumption situation by cost centre and ways to scale them down for their memorisation on site or by means of centralised supervision software thus making all the data available to all the relevant parties such as the Energy Manager, Engineering Offices, ESCo or more simply to the manager of an apartment block who needs to divide up the costs of shared spaces among the various occupiers.

Creation of an RS485 line

In order to minimise any interferences in the external environment with regard to the serial communication thereby obtaining maximum efficiency, it is necessary to adopt some small but essential technical features.

The most important and the least difficult of all is the one of physically separating the supply or power cables from the communication ones and route them as far as possible from remote switches, moving iron and high power motors.

This condition must also be complied inside the electric panel. For proper communication it is necessary to assign a unique node address (from 1 to 255) to the devices present on the line.




(1) Type of cable

For the RS485 connections we recommend an cable Belden type 9842, Belden 3106A (or equivalent) for a maximum bus length of 1000m, or cable Category 6 (FTP or UTP) for a maximum length of 50m

(*) Resistance not supplied with the device.

What to avoid

Do not create networks with nodes, rings or branches that may cause interferences or malfunctioning, do not use cables with different cross sections in the same RS485 line, do not exceed the 1000m line limit or the 31 devices connected serially without using a IF2E003 repeater.



Energy meters for sub metering application

Multi measurement unidirectional energy meters show active energy consumption (kWh) in class 1 EN/IEC 62053-21 and reactive energy (kvarh) in class 2 EN/IEC 62053-23 as well as the main electrical measurements on LCDs.



Conto D1 (NT868)

Direct-connected unidirectional energy meter on 1PH+N single phase networks up to 10kW
1 DIN module - 20mA starting current
True RMS of: kWh, kvarh, A, V, kW, kvar, kVA, cosφ, h

Cat. Nos.	Current	Voltage	Aux	Output
CE11165A4	up to 45A	230V	Self supplied	RS485 Modbus RTU



Conto D2 (NT765)

Direct-connected unidirectional energy meter on 1PH+N single phase networks up to 15kW
2 DIN modules - 20mA starting current
True RMS of: kWh, A, V, kW, Hz, cosφ, h

Cat. Nos.	Current	Voltage	Aux	Output
CE20195A2	up to 63A	230V	Self supplied	Pulses
CE20195A4	up to 63A	230V	Self supplied	RS485 Modbus RTU



Conto D4-Pd (NT669)

Direct-connected unidirectional energy meter on three phase 3PH/3PH+N networks up to 40kW
4 DIN modules - 40mA starting current
True RMS of: kWh, kvarh, A, V, kW, average kW, peak kW, kvar, kVA, Hz, cosφ, h

Cat. Nos.	Current	Voltage	Aux	Output
CE4DT06A2	up to 63A	400V	Self supplied	Pulses
CE4DT06A4	up to 63A	400V	Self supplied	RS485 Modbus RTU
CE4DT06AM	up to 63A	400V	Self supplied	M-Bus



Conto D6-Pd (NT902)

Direct-connected unidirectional energy meter on CT on 3PH/3PH+N networks up to 85kW
4 DIN modules - 40mA starting current
True RMS of: kWh, kvarh, A, V, kW, average kW, peak kW, kvar, kVA, Hz, cosφ, h

Cat. Nos.	Current	Voltage	Aux	Output
CE6DT1252	up to 125A	400V	Self supplied	Pulses
CE6DT1256	up to 125A	400V	Self supplied	Pulses + RS485 ModBus RTU



Conto D4-Pt (NT672)

Direct-connected unidirectional energy meter on CT on 3PH/3PH+N networks any power
4 DIN modules - 20mA starting current
True RMS of: kWh, kvarh, A, V, kW, average kW, peak kW, kvar, kVA, Hz, cosφ, h

Cat. Nos.	Current	Voltage	Aux	Output
CE4DT14A2	from CT/5A - CT/1A	400V	Self supplied	Pulses
CE4DT14A4	from CT/5A - CT/1A	400V	Self supplied	RS485 Modbus RTU
CE4DT14AM	from CT/5A - CT/1A	400V	Self supplied	M-Bus

Energy meters for tax purposes application



Multi measurement unidirectional energy meters suitable for applications for tax purposes.

They show active energy consumption (kWh) in class B EN 50740 MID certificate and reactive energy (kvarh) in class 2 EN/IEC 62053-23 as well as the main electrical measurements on LCDs.

Beginning of the operating hour counting linked to the starting current.



Conto D1 MID (NT867)

Direct-connected unidirectional energy meter on 1PH+N single phase networks up to 10kW
1 DIN module - 20mA starting current
Display of just one energy counting (kWh)

Cat. Nos.	Current	Voltage	Aux	Output
CE1DMID12	up to 45A	230 V	Self supplied	Pulses



Conto D2 MID (NT788)

Direct-connected unidirectional energy meter on 1PH+N single phase networks up to 15kW
2 DIN modules - 40mA starting current
True RMS of: kWh, A, V, kW, Hz, cosφ, h

Cat. Nos.	Current	Voltage	Aux	Output
CE2DMID12	up to 63A	230 V	Self supplied	Pulses
CE2DMID11	up to 63A	230 V	Self supplied	RS485 Modbus RTU



Conto D4-Pd MID (NT789)

Direct-connected unidirectional energy meter on 3PH/3PH+N networks up to 40kW
4 DIN modules - 40mA starting current
True RMS of: kWh, kvarh, A, V, kW, average kW, peak kW, kvar, kVA, Hz, cosφ, h

Cat. Nos.	Rete	Current	Voltage	Aux	Output
CE4DMID32	3F+N	up to 63A	400 V	Self supplied	Pulses
CE4DMID31	3F+N	up to 63A	400 V	Self supplied	RS485 Modbus RTU
CE4DMID3M	3F+N	up to 63A	400 V	Self supplied	M-Bus
CE4DMID22	3F	up to 63A	400 V	Self supplied	Pulses
CE4DMID21	3F	up to 63A	400 V	Self supplied	RS485 Modbus RTU



Conto D6-Pd MID (NT919)

Direct-connected unidirectional energy meter on 3PH/3PH+N networks up to 85kW
6 DIN modules - 40mA starting current
True RMS of: kWh, kvarh, A, V, kW, average kW, peak kW, kvar, kVA, Hz, cosφ, h

Cat. Nos.	Current	Voltage	Aux	Output
CE6DMID52	up to 125A	400V	Self supplied	Pulses
CE6DMID56	up to 125A	400V	Self supplied	Pulses + RS485 ModBus RTU



Conto D4-Pt MID (NT742)

Unidirectional energy meter on CT and possibly VT for 3PH/3PH+N networks any power
4 DIN modules - 10mA starting current
True RMS of: kWh, kvarh, A, V, kW, average kW, peak kW, kvar, kVA, Hz cosφ, h

Cat. Nos.	Current	Voltage	Aux	Output
CE4DMID01	from CT/5A	400V o ta TV	230Vac	Pulses + RS485 ModBus RTU
CE4DMID0M	from CT/5A	400V o ta TV	230Vac	Pulses + M-bus

Multifunction instruments with single harmonic analysis

Connection on the 1PH+N/3PH/3PH+N for LV networks through CT and VT (primary max 1kV)

Wide backlit 4 line LCD

Bidirectional active energy (kWh) counting in class 0.5 and reactive (kvarh) in class 1 according to EN/IEC 61557-12

Harmonic analysis for current and voltage up to 50th + crest factor

Counting threshold of operating hours that can be set in power

True RMS of: kWh, kvarh, A, V, kW, kvar, kVA, Hz cosφ, h, A, kW, kvar, kVA average value



NEMO D4-Le (NT864)

4 DIN modules

Cat. Nos.	Current	Voltage	Aux	Output
MFD4411	from CT/5A -CT/1A	80...500 V o from VT	80...265 Vac 100...300 Vdc	Pulses or alarms
MFD4421	from CT/5A -CT/1A	80...500 V o from VT	80...265 Vac 100...300 Vdc	Pulses or alarms + RS485 Modbus RTU/TCP



KIT NEMO D4-Le + Rogowski coils (NT889)

KIT ready for installation including 1 multifunction + 3 Rogowski coils

3 current ranges that can be selected on each KIT: 20...1000A, 60...3000A, 100...5000A

Cat. Nos.	Current	Voltage	Aux	Output
KRNEMOD4LE080	from Rogowski ø80	80...500 V o from VT	80...265 Vac 100...300 Vdc	Pulses or alarms + RS485 Modbus RTU/TCP
KRNEMOD4LE142	from Rogowski ø142	80...500 V o from VT	80...265 Vac 100...300 Vdc	Pulses or alarms + RS485 Modbus RTU/TCP
KRNEMOD4LE190	from Rogowski ø190	80...500 V o from VT	80...265 Vac 100...300 Vdc	Pulses or alarms + RS485 Modbus RTU/TCP



NEMO 72-Le (NT879)

flush mounting, 72x72mm

Cat. Nos.	Current	Voltage	Aux	Output
MF72411	from CT/5A -CT/1A	80...500 V o from VT	80...265 Vac 100...300 Vdc	Pulses or alarms
MF72421	from CT/5A -CT/1A	80...500 V o from VT	80...265 Vac 100...300 Vdc	Pulses or alarms + RS485 Modbus RTU/TCP



NEMO 96 HDLe (NT854)

flush mounting, 96x96mm - expandable with plug-in modules

Cat. Nos.	Current	Voltage	Aux	Output
MF96411	from CT/5A -CT/1A	80...500 V o from VT	80...265 Vac 100...300 Vdc	Pulses + 1 plug-in module
MF96421	from CT/5A -CT/1A	80...500 V o from VT	80...265 Vac 100...300 Vdc	Pulses + RS485 Modbus RTU/TCP + 1 plug-in module



KIT NEMO 96 HDLe + Rogowski coils (NT890)

KIT ready for installation including 1 multifunction + 3 Rogowski coils

3 current ranges that can be selected on each KIT: 20...1000A, 60...3000A, 100...5000A

Cat. Nos.	Current	Voltage	Aux	Output
KRNEMOHDLE080	from Rogowski ø80	80...500 V o from VT	80...265 Vac 100...300 Vdc	Pulses + RS485 Modbus RTU/TCP + 1 plug-in module
KRNEMOHDLE142	from Rogowski ø142	80...500 V o from VT	80...265 Vac 100...300 Vdc	Pulses + RS485 Modbus RTU/TCP + 1 plug-in module
KRNEMOHDLE190	from Rogowski ø190	80...500 V o from VT	80...265 Vac 100...300 Vdc	Pulses + RS485 Modbus RTU/TCP + 1 plug-in module



NEMO 96 HD (NT900)

Flush mounting, 96x96mm

Cat. Nos.	Current	Voltage	Aux	Output
MF96E06	from CT/5A	80...460 V	Self supplied	Pulses + RS485 Modbus RTU/TCP



NEMO 96 HD (NT680)

Connected on LV networks by means of CT and VT (primary max 1kV)
flush mounting 96x96mm


Cat. Nos.	Current	Voltage	Aux	Output
MF96001	from CT/5A -CT/1A	80...500 V o from VT	80...265 Vac 100...300 Vdc	up to 4 plug-in modules



NEMO 96 HD+ (NT904)

Connected on LV/MV networks by means of CT and VT, I/U harmonic analysis
flush mounting 96x96mm

Cat. Nos.	Current	Voltage	Aux	Output
MF96021A	from CT/5A -CT/1A	80...690 V o from VT	80...265 Vac 100...300 Vdc	up to 4 plug-in modules



NEMO 96 Plug-in modules

The purpose of the plug-in modules is to add new functions to the Nemo 96 HD/HD+/HDLe

Cat. Nos.	Description	Position	HDle	HD+	HD	Technical note
IF96001 ¹	RS485 Modbus RTU/TCP	A	●	●	●	NT675
IF96012 ¹	RS485 Modbus RTU/TCP + memory	A	●	●	●	NT704
IF96002 ¹	RS232 Modbus RTU/TCP	A	●	●	●	NT676
IF96007A ¹	Profibus EN50170 - DP0	A	●	●	●	NT682
IF96009 ¹	LonWorks	A	●	●	●	NT684
IF96013 ¹	M-Bus EN1434-3	A	●	●	●	NT707
IF96014 ¹	RS485 BACnet MS-TP	A	●	●	●	NT743
IF96015 ¹	Ethernet	A	●	●	●	NT785
IF96003	2 energy pulse outputs (SPST)	A-B-C-D		●	●	NT677
IF96004	2 x 0/4...20mA analogue outputs	C-D		●	●	NT678
IF96005	2 alarm relay outputs (SPST)	A-B-C-D		●	●	NT679
IF96006	Neutral current direct connection (max.5A) or with external dedicated CT	C		●	●	NT683
IF96016	Temperature measurement 2 inputs from PT100	C		●	●	NT810
IF96010	2 input SPST-NO - 2 relay outputs SPST-NO	C-D		●	●	NT702
IF96011	2 input 12/24Vcc - 2 relay outputs SPST-NO	C-D		●	●	NT703

¹ Communication modules are as an alternative to them.

NEMO 96EA

NETWORK ANALYSER WITH ENERGY QUALITY DISPLAY



NEMO 96 EA is a Class S Power Quality Analyzer, allowing you to monitor the quality of the network that is measuring and recording events that may occur. It will help you manage and guarantee the reliability and energy efficiency of your installation in order to minimize losses due to disturbances in the distribution networks.

NEMO 96 EA has an 8Mb internal memory for the recording of real time data (current, voltage, powers, frequency,...) and integrated data (energies). It can also save the energy NEMO 96 EA quality events (voltage drops, overvoltage, rapid voltage change and interruptions of the voltages). It calculates the instantaneous flicker intensity.

Integrated memory

Thanks to **integrated memory**, is possible choose what parameters to store and keep track of for the future analysis.

Parameter display and thresholds and alarm management

NEMO 96 EA is able to display all network parameters and setting alarm thresholds.

Energy quality display

IDM EVO software can remotely view the power quality parameters of your network.



Reply of display

IDM EVO software lets you remotely replicate the parameters displayed on the display of the control panel and handle them through dedicated functions.

Remote configuration

IDM EVO software in addition to the display function, the IDM EVO software also allows the complete configuration of the device and the connected modules.

Accessoriability with standard modules


NEMO 96 EA can be equipped with up to 3 additional modules, including those normally in the catalog for the NEMO 96 range.



NEMO 96 EA (NT905)

Network analyser, class S, connected on LV/MV networks by means of CT and VT flush mounting 96x96mm

Cat. Nos.	Current	Voltage	Aux	Output
MFQ96021	from CT/5A -CT/1A	80...690 V o from VT	80...265 Vac 100...300 Vdc	RS485 Modbus RTU/TCP + up to 3 plug-in modules



NEMO 96 PLUG-IN MODULES

The purpose of the plug-in modules is to add new functions to the Nemo 96 EA

Cat. Nos.	Description	Position	EA	Technical note
IF96002 ¹	RS232 Modbus RTU/TCP	A	●	NT676
IF96015 ¹	Ethernet	A	●	NT785
IF96003	2 energy pulse outputs (SPST)	B-C-D	●	NT677
IF96004	2 x 0/4...20mA analogue outputs	C-D	●	NT678
IF96005	2 alarm relay outputs (SPST)	B-C-D	●	NT679
IF96006	neutral current direct connection (max.5A) or with external dedicated CT	C	●	NT683
IF96016	Temperature measurement 2 inputs from PT100	C	●	NT810
IF96010	2 input SPST-NO - 2 relay outputs SPST-NO	C-D	●	NT702
IF96011	2 input 12/24Vcc - 2 relay outputs SPST-NO	C-D	●	NT703

¹ Communication modules are as an alternative to them.

IF4E011

RS485/ETHERNET STAND-ALONE INTERFACE WITH BUILT-IN DATALOGGER



Stand-alone interface

The new IF4E011 interface is able to store energy consumptions from up to 64 instruments in the **Nemo** and **Conto** series.

A powerful new stand-alone instrument that stores the data in loco and makes it available on the network. It can be displayed directly from its web-based console without needing to install any software or dedicated PC.

User friendliness

- No dedicated PC or software is necessary
- All you need is a browser like Internet Explorer, Chrome, Mozilla, Firefox or Safari to access the IF4E011 interface, configure it and display the data it contains.
- Multisession, up to 4 users connected at the same time
- Internal memory up to 400 days that can be downloaded in csv files

2 password levels

ADMINISTRATOR

- Creation, editing and cancellation of users
- Daily/monthly/yearly consumption reports by individual users or groups of users
- Consumption reports via email that can be automatically configured

USER

- Daily/monthly/yearly consumption report display

Communication interfaces

Interfaces that allow the conversion of communication protocols, useful for creating monitoring systems.



Interface RS485/USB communication (NT892)

USB-RS485 converter interface allows the direct connection to a PC of the Conto energy meters and Nemo multifunctions with RS485 output. Recommended exclusively for local use. Useful for programming on site and the downloading of data from the storage module IF96012 combined with the free IDM Evolution software that can be downloaded from the site.

Cat. Nos.	Input	Output	Aux
IFUSB01	RS485	USB	Self supplied



Interface RS485/Ethernet communication (NT809)

Ethernet-RS485 converter interface, 2 DIN modules, makes it possible to interface Conto energy meters and Nemo multifunctions to an Ethernet network 10/100MB. Direct connection up to 31 devices on the RS485 line or up to 247 devices using repeaters. Two methods of Bridge functioning (ModbusRTU or Over TCP) or Web Server functioning for the reading of the main parameters and relative download in csv format through an ordinary Internet browser.

Cat. Nos.	Input	Output	Aux
IF2E011	RS485	Ethernet RJ45	80...270 Vac + 100...300 Vdc



Booster interface RS485/RS485 (NT694)

RS485-RS485 repeater interface, 2 DIN modules, makes it possible to amplify the signal for another 31 devices over a distance of 1000m connected on the same RS485 line

Cat. Nos.	Input	Output	Aux
IF2E003	RS485	RS485	80...270 Vac + 100...300 Vdc



Interface RS485-KNX (NT918)

KNX/Modbus RS485 converter interface, for Conto energy meters and Nemo multifunctions, up 31 struments

Cat. Nos.	Input	Output	Aux
IF1KNX	RS485	KNX	95...250Vac

Display and data storage

Software and interfaces for completing the monitoring network, making the configuration from a remote position, displaying the measurements read and making a report of the energy consumptions.



IDM Evolution

Management SW for local and/or remote monitoring networks with Conto and Nemo multifunction meters. It allows the real time display of the measurements taken by the devices on site and the remote programming for all the instruments and interfaces of the Nemo series and for Conto imp. Installation on PC for workstation operating systems Windows XP, SP3, Windows 7 32 and 64 bit, Windows 8 32 and 64 bit and Windows 8.1 32 and 64 bit

Free download: <http://www.imeitaly.com/uk/idmevouk.asp>



IF with built-in datalogger

Ethernet-RS485/Datalogger multisession converter interface (up to 4), 4 DIN modules makes it possible to interface Conto and Nemo multifunction meters to an Ethernet 10/100 MB network. Direct connection up to 31 devices on the RS485 line or up to 247 devices using repeaters. Two methods of Bridge (Modbus RTU or TCP) or Datalogger function for storing energy data for each device connected and on request generating consumption reports for a period selected with the possibility of delivery to the system administrator by mail. In this configuration it is possible to manage up to 64 different energy meters/multifunction and users with individual access to a system administrator.

Cat. Nos.	Input	Output	Aux
IF4E011	RS485	Ethernet RJ45	80...270 Vac + 100...300 Vdc



MIDAs Evo Software

Management SW for local and/or remote monitoring networks with Conto and Nemo multifunction meters. It enables realtime display of the measurements read by the devices on site and the creation of daily/monthly/annual consumption reports for tariffs that can be set beforehand. Possibility of setting software alarm thresholds with the sending of an email. Installation on the PC with workstation Windows XP SP3, Windows 7 32 and 64bit, Windows 8 32 and 64bit, Windows 8.1 32 and 64bit operating systems, , Windows 10 sia in versione 32 che 64 bit.

Cat. Nos.	Instruments managed
SWMF2	Licence up to 5 devices
SWMF3	Licence up to 20 devices
SWMF4	Licence up to 1020 devices
SWMF5	Licence up to 100 devices

MIDAs Evo can be updated free of charge to the latest release available by connecting to page <http://www.imeitaly.com/uk/midasevouk.asp>

NEMO SX


MEASUREMENT AND MANAGEMENT SYSTEM

NEMO SX system is made up of several DIN modules.

Each of them performs a specific function: measurement, command or control of the status of protection or any kind of other devices.

NEMO SX is an independent and integrable system which, thanks to its type of automatic connection, simplifies the assembling step and does not require any modification of existing panels.

Its mechanical features mean that it can be used with a wide range of protection devices or all type of other devices in all distribution panels and cabinets.



New **NEMO SX** measurement and energy management system completes the already existing IME measurement offers, by also offering possibilities of:

Check if the system is running properly

- Measure electrical
- Display the status of circuit breakers and loads, faults and general system conditions locally or remotely.



Directly control the system

- Take the control devices locally or remotely, via manual or automatic actions.



Monitor the system in the installation or remotely

- Monitor and control all the processes via computing tools to optimise energy consumption at any time and everywhere:
- Check the status of devices or loads
- Remote control circuits
- Programmed maintenance
- Corrective actions on the system
- Management of signals and alarms
- Historical analysis of consumptions over time



Moreover system monitoring is allowed, using on 1 dedicated PC via USB licence key on on several devices: PC, tablet and smartphone through https page issued by Energy Web Servers.

Local monitoring directly from the mini configuration module (local display)




Remote monitoring via pc/smartphone/tablet


a) Via computer



b) Via web server



“Multisite” remote monitoring via pc/smartphone/tablet




Measurement and energy management system NEMO SX



Power supply module (NT906)

stabilized power supply

Cat. Nos.	Description
SXAA230	stabilized power supply



Communication rails for rail DIN35

Allows data transmission between the different modules of NEMO SX energy management system

Cat. Nos.	Description
SXAR18	18 modules
SXAR24	24 modules
SXAR36	36 modules
SXARC	Plastic cover for communication rail



Communication patch cords

Allows data transmission between the different modules of NEMO SX energy management system
Can be used instead of communication rails or to create a link between two rows (individually connected with communication rails)

Cat. Nos.	Description
SXAC250	Kit 10 cables L=250mm
SXAC500	Kit 10 cables L=500mm
SXAC1000	Kit 10 cables L=1000mm
SXACA	Communication patch cord connector (maximum length 3m)



Measurement modules (NT907-908)

NEMO SX measuring devices available with rogowsky coils supplied or external CTs.

Measurements performed and precision

- Current (0.5 precision): phase: I1, I2, I3 - neutral: IN
- Voltage (0.5 precision): phase / phase: U12, U23, U31-phase/neutral: V1N, V2N, V3N
- Frequency (accuracy 0.1)
- Power: total instantaneous, phase active (precision 0.5); total instantaneous reactive, phase (precision 2); apparent total instantaneous, phase (accuracy 0.5);
- Power factor (precision 1)
- Energy: total / partial active energy, positive and negative (precision 0,5); total / partial reactive energy, positive and negative (precision 2).
- THD (precision 5): THD voltages: V1, V2, V3 or U12, U23, U31; THD currents: I1, I2, I3, IN.
- Voltage / current harmonic analysis: odd harmonics up to 15th

Cat. Nos.	Description
SXMM63	Single-phase measuring module and closed Rogowski coil up to 63 A
SXMT63	3-phase measuring module and closed Rogowski coil up to 63 A
SXMMT5	5 A measuring module connected via current transformers (CT)



State reporting module (NT912)

Equipped with 3 LED lights: green, red and yellow Indicates various type of information, according to selected configuration: contacts position, plugged-in or drawn-out product, etc...

Equipped with DIP switches (on the side) allowing product configuration: selection of information type and of the LED behaviour

Cat. Nos.	Description
SXMC02	LED module Equipped with 3 LED lights: green, red and yellow



Control module (NT913)

Enables to remotely control different electrical loads or motorised controls associated to 4 rail mounting protection devices or head equipment.

Equipped with DIP switches (on the side) allowing product configuration: contact type (NO + NC, 2 NO, etc...) and function (maintained or momentary contact)

Cat. Nos.	Description
SXM0C1	Control module with two buttons



Communication interfaces RS485 module (NT909)

RS485 / NEMO SX energy management system conversion

Cat. Nos.	Description
SXI485	Communication interfaces module NEMO SX to RS485



Communication interfaces RS485 / Modbus TCP-IP module (NT914)

Modbus RS485 - Modbus TCP / IP conversion, allowing the devices in the electrical panel to be connected to an Ethernet network.

Cat. Nos.	Description
SXIIP	RS485 / Ethernet conversion (for connection to an IP network)



Pulse concentrator module (NT910)

For collecting and transmitting measurements taken by universal pulse energy meters (water, gas, etc...) Up to 3 pulse circuits

Cat. Nos.	Description
SXMIMP	Pulse concentrator module



Mini modular configurator (NT911)

Optional module for «stand alone» supervision need. Enables to configure, test and control NEMO SX energy management system and to visualize supervision data No computer or IP connection required.

Cat. Nos.	Description
SXV01	Stand alone configuration module



Software

Allows remote configuration, test, control and visualization of data collected from energy meters and multi-function measuring units and NEMO SX energy management system on one computer connected to the network. 30-day free trial version available for download via www.imeitaly.com

Cat. Nos.	Description
SXS32	Software licence agreement (user key) for 32 Modbus addresses or 32 pulse modules
SXS255	Software licence agreement (user key) 255 Modbus addresses or 255 pulse modules



Mini Web server DIN version (NT915)

Allow remote configuration, test, control and visualization, via a web browser on PCs, smartphones, web viewers, tablet computers, of data collected from: protection devices, meters and multi-function measuring units and NEMO SX energy management

Cat. Nos.	Description
SXWS10	For 10 Modbus addresses or 10 pulse modules
SXWS32	For 32 Modbus addresses or 32 pulse modules




Web server (NT916)

Allow remote configuration, test, control and visualization, via a web browser on PCs, smartphones, web viewers, tablet computers, of data collected from: protection devices, meters and multi-function measuring units and NEMO SX energy management

Cat. Nos.	Description
SXWS225	It manages up to 255 Modbus addresses

LOW VOLTAGE TRANSFORMERS



GUIDE TO CHOOSE A CT

To choose the CT properly you need to know:

- System rated current

This is used to determine the transformer's primary current, e.g.:
System rated current: 425A = CT 500/5A

- Power bar/cable size

This makes it possible to choose a CT with a window that is large enough to pass the phase bar/ cord through, the tendency is always to choose a slightly bigger window so as to have a little play that is useful during installation, e.g.:

Cord of 120mm² (max. outer diam. 21.5mm) = I choose model TA327 with ø27mm hole.

- Measurement class

Classes 0.5/1 recommended for measuring power, electricity and cosφ
Class 3 to be used for current measures on ammeters only

- Performance (VA)

This represents the maximum load that can be connected to the secondary terminals of the CT. The load consists of the self consumption of the measurement instrument + adsorption of the cables connecting the CT and the instrument. This latter depends on the length and cross-section of the cable.

The following is a table for calculating the absorption of the cables connecting the CT and the instrument.

Power absorbed (VA) by the cables connecting the CT and the instrument		
cross section mm ² copper	*VA per meter of bipolar cable at 20°C	
	secondary 5A	secondary 1A
1	1	0.04
1.5	0.685	0.0274
2.5	0.41	0.0164
4	0.254	0.0102
6	0.169	0.0068
10	0.0975	0.0039
16	0.062	0.0025

*The VA absorbed by the connection cables rises 4% for every 10% variation in the temperature.

CT/5A or CT/1A?

From the table shown above, it can be seen that using the same cross section the CT/1A absorbs 25 times less than the CT/5A because of the very long sections (≥20m). You are advised to choose a CT/1A so as to reduce the section and relative cost of the cables as well as ensuring more precise reading.


When taking industrial electrical measurements they are the first link in the measurement chain.

Current transformers make it possible to work back to the precise current value applied to the primary through the measurement of the secondary current.

They are used from the simplest applications with analogic indicators to the most complex where the use of transducers, energy meters or multifunction instruments is contemplated and, finally, in monitoring systems.

CT with cable/passing bar (Primary currents: 40...8000A)

By making several passages (turns) of the cable inside the transformer, it is possible to reduce the value of the primary current while keeping the unchanged secondary current values, performances, class (actual primary current = rated primary current: n° of turns; example 150/5A with 2 cable passages = 75/5A with 3 cable passages = 50/5A)



CT with primary winding (Primary currents: 5...600A)



Open core CT (Primary currents: 60...5000A)

Ideal for being installed in existing systems, they can be installed without breaking the primary circuit or modifying the system.




CT connections

The terminals of current transformers are marked with double wording:

Primary circuit P1(K) - P2(L)

Secondary circuit s1(k) - s2(l)



Mounting

Some models have also been fitted with arrows indicating the proper way of CT connection on the cable/bar to avoid current inversion errors.





Connection

The secondary terminals, depending on the models, might be nut tightening, screws, double faston + screw, the latter useful for short circuiting the CT secondary before disconnecting the devices to avoid dangerous voltages generated by the opening of the circuit (no-load operation).

Safety

In any event, to avoid this situation for all current transformers, IME suggest a fully static accessory (ATAP015) able to instantly reclose the CT secondary circuit, which was open due to connection breakdown or device removal, allowing the instantaneous and automatic restore of standard conditions. Secondary terminal protection degree IP20 (for the TAS...TAU...TAQ...BSA... models only with the use of the sealable terminal cover accessory).



Cable/
passing bar

		TAIBB (NT516)			TA221 (NT811)				TA327 (NT812)				TA432 (NT814)				TA540 (NT815)			
Dimensions (mm)		44x65			49.5x80				56x80				70x95				70x95			
Cable (mm)		Ø21			Ø21				Ø27				Ø32				Ø40			
Window (mm)		16x12.5			20.5x10.5				25.5x15.5 32.5x10.5				25.5x25.5 32.5x20.5				40.5x20.5 50.5x12.5			
Ratio	Cat. Nos.	VA			Cat. Nos.	VA			Cat. Nos.	VA			Cat. Nos.	VA			Cat. Nos.	VA		
		cl.0.5	cl.1	cl.3		cl.0.5	cl.1	cl.3		cl.0.5	cl.1	cl.3		cl.0.5	cl.1			cl.0.5	cl.1	
40/5A	TABB50B400	-	-	1	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
50/5A	TABB50B500	-	-	1.5	TA22150B500	-	-	2.5	TA32750B500	-	-	1.5	-	-	-	-	-	-	-	-
60/5A	TABB50B600	-	-	2	TA22150B600	-	1.5	3	TA32750B600	-	-	2.5	-	-	-	-	-	-	-	-
75/5A	TABB50B750	-	1.5	2.5	TA22150B750	-	2	4	TA32750B750	-	1.5	3	-	-	-	-	-	-	-	-
80/5A	TABB50B800	-	1.5	2.5	TA22150B800	-	3	4	TA32750B800	-	2.5	3.5	-	-	-	-	-	-	-	-
100/5A	TABB50C100	1.5	2.5	-	TA22150C100	1.5	3	-	TA32750C100	1.5	3	-	TA43250C100	-	2	-	-	-	-	-
120/5A	TABB50C120	2	3.5	-	TA22150C120	2.5	4	-	TA32750C120	2	3.5	-	TA43250C120	-	2	-	-	-	-	-
125/5A	TABB50C125	2	3.5	-	TA22150C125	2.5	4	-	TA32750C125	2	3.5	-	TA43250C125	-	2	-	-	-	-	-
150/5A	TABB50C150	3	4	-	TA22150C150	4	6	-	TA32750C150	3	4	-	TA43250C150	1	3	-	-	-	-	-
160/5A	TABB50C160	3	4	-	TA22150C160	4	6	-	TA32750C160	3	5	-	TA43250C160	1.5	3	-	-	-	-	-
200/5A	TABB50C200	4	5.5	-	TA22150C200	6	8	-	TA32750C200	4	7	-	TA43250C200	3	5	-	-	-	-	-
250/5A	TABB50C250	5	6	-	TA22150C250	8	10	-	TA32750C250	6	8	-	TA43250C250	3	5	-	-	-	-	-
300/5A	TABB50C300	6	7.5	-	TA22150C300	8	10	-	TA32750C300	8	10	-	TA43250C300	5	8	TA54050C300	2	4		
400/5A	-	-	-	-	-	-	-	-	TA32750C400	10	12	-	TA43250C400	8	10	TA54050C400	4	6		
500/5A	-	-	-	-	-	-	-	-	TA32750C500	12	15	-	TA43250C500	10	12	TA54050C500	4	6		
600/5A	-	-	-	-	-	-	-	-	TA32750C600	15	20	-	TA43250C600	12	15	TA54050C600	6	8		
800/5A	-	-	-	-	-	-	-	-	-	-	-	-	TA43250C800	10	12	TA54050C800	8	12		
1000/5A	-	-	-	-	-	-	-	-	-	-	-	-	TA43250D100	12	15	TA54050D100	10	12		
1200/5A	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	TA54050D120	12	15		
Sealable terminal cover	ATACOP12				ATACOP13				ATACOP13				ATACOP13				ATACOP13			

Cable/
passing bar

		TAS64 (NT569)				TAS65 (NT518)				TAS84 (NT574)				TAS102 (NT766)				TAS127B (NT523)			
Dimensions (mm)		90x130				90x94				96x116				98x129				125x160			
Window (mm)		51x31 64x11				32x65				34x84				38x102				54x127			
Ratio	Cat. Nos.	VA		Cat. Nos.	VA		Cat. Nos.	VA		Cat. Nos.	VA		Cat. Nos.	VA		Cat. Nos.	VA				
		cl.0.5	cl.1		cl.0.5	cl.1		cl.0.5	cl.1		cl.0.5	cl.1		cl.0.5	cl.1		cl.0.5	cl.1			
600/5A	TASI50C600	4	6	TASL50C600	8	12	TASO50C600	6	10	-	-	-	-	-	-	-	-	-			
800/5A	TASI50C800	6	8	TASL50C800	12	15	TASO50C800	8	12	-	-	-	-	-	-	-	-	-			
1000/5A	TASI50D100	8	10	TASL50D100	15	20	TASO50D100	10	15	TAMP50D100	10	12	-	-	-	-	-	-			
1200/5A	TASI50D120	10	12	TASL50D120	15	20	TASO50D120	12	15	TAMP50D120	12	15	-	-	-	-	-	-			
1250/5A	TASI50D125	10	12	TASL50D125	15	20	TASO50D125	12	15	TAMP50D125	12	15	-	-	-	-	-	-			
1500/5A	TASI50D150	10	12	TASL50D150	20	25	TASO50D150	15	20	TAMP50D150	12	15	TASS50D150	20	30	-	-	-			
1600/5A	TASI50D160	10	12	TASL50D160	20	25	TASO50D160	15	20	TAMP50D160	12	15	TASS50D160	20	30	-	-	-			
2000/5A	-	-	-	TASL50D200	20	25	TASO50D200	20	25	TAMP50D200	20	25	TASS50D200	25	30	-	-	-			
2500/5A	-	-	-	-	-	-	TASO50D250	25	30	TAMP50D250	20	25	TASS50D250	30	50	-	-	-			
3000/5A	-	-	-	-	-	-	-	-	-	TAMP50D300	20	25	TASS50D300	30	50	-	-	-			
4000/5A	-	-	-	-	-	-	-	-	-	-	-	-	TASS50D400	30	50	-	-	-			
Sealable terminal cover	ATACOP03					ATACOP04					ATACOP04					ATACOP04					

 In stock also in the version with terminals on the long side. Ordering code: add "3" at the end of the standard code.standard.

Open core CT



Dimensions (mm) Window (mm)	TRA230 (NT869)				TRA580 (NT841)				TRA812 (NT842)				TRA816 (NT863)			
	92x110 20.5x30.5				120x150 50.5x80.5				150x190 80.5x120.5				185x230 80.5x160.5			
Ratio	Cat. Nos.	VA			Cat. Nos.	VA			Cat. Nos.	VA			Cat. Nos.	VA		
		cl.0.5	cl.1	cl.3		cl.0.5	cl.1			cl.0.5	cl.1	cl.3		cl.0.5	cl.1	
60/5A	TA23050B600	-	-	1	-	-	-	-	-	-	-	-	-	-	-	-
100/5A	TA23050C100	-	-	1.5	-	-	-	-	-	-	-	-	-	-	-	-
150/5A	TA23050C150	-	1.5	2.5	-	-	-	-	-	-	-	-	-	-	-	-
200/5A	TA23050C200	1	2.5	-	-	-	-	-	-	-	-	-	-	-	-	-
250/5A	TA23050C250	1.5	3	-	TA58050C250	1	2	-	-	-	-	-	-	-	-	-
300/5A	TA23050C300	1.5	4	-	TA58050C300	1.5	3	-	-	-	-	-	-	-	-	-
400/5A	TA23050C400	2.5	6	-	TA58050C400	1.5	3	-	-	-	-	-	-	-	-	-
500/5A	-	-	-	-	TA58050C500	2.5	5	TA81250C500	-	4	12	-	-	-	-	-
600/5A	-	-	-	-	TA58050C600	2.5	5	TA81250C600	-	5	14	-	-	-	-	-
800/5A	-	-	-	-	TA58050C800	3	7	TA81250C800	3	7	-	-	-	-	-	-
1000/5A	-	-	-	-	TA58050D100	5	10	TA81250D100	5	10	-	-	-	-	-	-
1200/5A	-	-	-	-	-	-	-	TA81250D120	6	11	-	-	-	-	-	-
1500/5A	-	-	-	-	-	-	-	TA81250D150	8	15	-	-	-	-	-	-
2000/5A	-	-	-	-	-	-	-	-	-	-	-	-	TA81650D200	15	20	-
2500/5A	-	-	-	-	-	-	-	-	-	-	-	-	TA81650D250	15	20	-
3000/5A	-	-	-	-	-	-	-	-	-	-	-	-	TA81650D300	20	25	-
4000/5A	-	-	-	-	-	-	-	-	-	-	-	-	TA81650D400	20	25	-
5000/5A	-	-	-	-	-	-	-	-	-	-	-	-	TA81650D500	20	25	-
Sealable terminal cover	ATACOP13				ATACOP13			ATACOP13					ATACOP13			

Primary winding



Dimensions (mm) Primary terminals	TAQ2M (NT881)				TAQ6M (NT883)				TAQ2L (NT882)				TAQ6L (NT884)			
	56x80 screw type, max. cross section 6mm ² /10mm ² with wire terminals								56x80 M6 with nut tightening							
Rapporto	Cat. Nos.	VA		Cat. Nos.	VA				Cat. Nos.	VA			Cat. Nos.	VA		
		cl.0.5	cl.1		cl.0.5	cl.1				cl.0.5	cl.1			cl.0.5	cl.1	
5/5A	TAQ2M50A500	2	4	TAQ6M50A500	6	7.5	-	-	-	-	-	-	-	-	-	-
10/5A	TAQ2M50B100	2	4	TAQ6M50B100	6	7.5	-	-	-	-	-	-	-	-	-	-
15/5A	TAQ2M50B150	2	4	TAQ6M50B150	6	7.5	-	-	-	-	-	-	-	-	-	-
20/5A	TAQ2M50B200	2	4	TAQ6M50B200	6	7.5	-	-	-	-	-	-	-	-	-	-
25/5A	TAQ2M50B250	2	4	TAQ6M50B250	6	7.5	-	-	-	-	-	-	-	-	-	-
30/5A	TAQ2M50B300	2	4	TAQ6M50B300	6	7.5	-	-	-	-	-	-	-	-	-	-
40/5A	TAQ2M50B400	2	4	TAQ6M50B400	6	7.5	-	-	-	-	-	-	-	-	-	-
50/5A	-	-	-	-	-	-	TAQ2L50B500	2	4	TAQ6L50B500	6	7.5	-	-	-	-
60/5A	-	-	-	-	-	-	TAQ2L50B600	2	4	TAQ6L50B600	6	7.5	-	-	-	-
75/5A	-	-	-	-	-	-	TAQ2L50B750	2	4	TAQ6L50B750	6	7.5	-	-	-	-
80/5A	-	-	-	-	-	-	TAQ2L50B800	2	4	TAQ6L50B800	6	7.5	-	-	-	-
100/5A	-	-	-	-	-	-	TAQ2L50C100	2	4	-	-	-	-	-	-	-
Sealable terminal cover	ATACOP13			ATACOP13			ATACOP13			ATACOP13			ATACOP13			

NETWORK PROTECTION



DELTA the range of residual current relays with a separate external toroid, available with modular and flush mounting devices.

The range of Delta relays are the ideal for use in the industrial and service sectors, in public lighting and in building automatic machines, they comply with standards of protection CEI EN standard 60947-2 appendices B and M class A, anyway compatible with pulsing currents.



RESIDUAL CURRENT RELAYS DELTA CHARACTERISTICS

Permanent connection control.

An important feature of the Delta series is the permanent connection control of circuit between residual current relay and C.T.: by detecting of any anomaly in the connection between C.T. and E.L.R., the protection automatically intervenes, without waiting for the periodic check to carry out by test push button.

Δt intervention time adjustment.

The Δt tripping time adjustment makes this series ideal for the creation of selective protection systems; adjustment in $I_{\Delta n}$ current makes it possible to protect people and property against undesired or dangerous dispersions.

Version with harmonic filter.

With the evolution of system requirements and the introduction into the systems of devices fitted with power electronics, the F models have been created with harmonic filter for systems that are subject to considerable disruption.

Residual current relays

Class A EN60947-2:2007 appendix B and M - edition 8, $I_{\Delta n}$ ranges that can be selected from 0.03 to 30A.

All the relays can be used in positive or negative safety mode that can be selected and they carry out the automatic permanent test of continuity of the connection to the differential ring transformer (Del - Del A).



DELTA D2-L (NT544)

2 DIN modules - manual or automatic reset (3 attempts) that can be selected

Cat. Nos.	1st relay	2nd relay	Aux
RD1AF13B	TRIP	-	230 Vac
RD1AF1HB	TRIP	-	20...150 Vdc + 48 Vac



DELTA D4-s (NT871)

4 DIN modules - manual or automatic reset (10 attempts) that can be selected - LED bar indicator $I_{\Delta n}\%$

Cat. Nos.	1st relay	2nd relay	Aux
RD4B213B	TRIP	TRIP or pre-alarm 50% $I_{\Delta n}$	230 Vac
RD4B21HB	TRIP	TRIP or pre-alarm 50% $I_{\Delta n}$	20...150 Vdc + 48 Vac



DELTA D4-h (NT897)

4 DIN modules - manual or automatic reset that can be selected - LED Display indicator $I_{\Delta n}$, with harmonic filter

Cat. Nos.	1st relay	2nd relay	Aux	Output
RDD42130	TRIP	TRIP or pre-alarm 50% $I_{\Delta n}$	230 Vac	-
RDD421H0	TRIP	TRIP or pre-alarm 50% $I_{\Delta n}$	20...150 Vdc + 48 Vac	-
RDD42131	TRIP	TRIP or pre-alarm 50% $I_{\Delta n}$	230 Vac	RS485 Modbus RTU/TCP
RDD421H1	TRIP	TRIP or pre-alarm 50% $I_{\Delta n}$	20...150 Vdc + 48 Vac	RS485 Modbus RTU/TCP



DELTA 48-s (NT556)

Flush mounting 48x48mm - manual or automatic reset (3 attempts) that can be selected

Cat. Nos.	1st relay	2nd relay	Aux
RD1DF13B	TRIP	-	230 Vac
RD1DF1HB	TRIP	-	20...150 Vdc + 48 Vac



DELTA 72-s (NT552)

Flush mounting 72x72mm - manual or automatic reset (3 attempts) that can be selected - LED bar indicator $I_{\Delta n}\%$

Cat. Nos.	1st relay	2nd relay	Aux
RD1EP13B	TRIP	pre-alarm 50% $I_{\Delta n}$	230 Vac
RD1EP1HB	TRIP	pre-alarm 50% $I_{\Delta n}$	20...150 Vdc + 48 Vac



DELTA 72-h (NT649)

Flush mounting 72x72mm - manual reset - LED Display indicator $I_{\Delta n}$

Cat. Nos.	1st relay	2nd relay	Aux
RD3E217B	TRIP	TRIP or pre-alarm 50% $I_{\Delta n}$	230 Vac
RD3E21HB	TRIP	TRIP or pre-alarm 50% $I_{\Delta n}$	20...150 Vdc + 48 Vac



DELTA 96-s (NT691)

Flush mounting 96x96mm - manual reset - LED bar indicator $I_{\Delta n}\%$

Cat. Nos.	1st relay	2nd relay	Aux
RD1G213B	TRIP	pre-alarm 50% $I_{\Delta n}$	230 Vac
RD1G21HB	TRIP	pre-alarm 50% $I_{\Delta n}$	20...150 Vdc + 48 Vac

Residual current relays with strengthened harmonic filter

Class A EN60947-2:2007 appendix B and M - edition 8, $I_{\Delta n}$ ranges that can be selected from 0.05 to 30A.

The strengthened harmonic filter makes it possible to avoid untimely tripping in systems subject to considerable harmonic disturbances. All the relays can be used in positive or negative safety mode that can be selected and they carry out the automatic permanent test of continuity of the connection to the differential toroid (Del - Del A).



DELTA D4-F (NT865)

4 DIN modules - manual reset - LED bar indicator $I_{\Delta n}\%$

Cat. Nos.	1st relay	2nd relay	Aux
RD3B213B	TRIP	pre-alarm at 50% $I_{\Delta n}$ or on power fail	230 Vac
RD3B21HB	TRIP	pre-alarm at 50% $I_{\Delta n}$ or on power fail	20...150 Vdc + 48 Vac



DELTA 72-F (NT745)

Flush mounting 72x72mm - manual reset - LED bar indicator $I_{\Delta n}\%$

Cat. Nos.	1st relay	2nd relay	Aux
RD2E213B	TRIP	TRIP or pre-alarm 50% $I_{\Delta n}$	230 Vac
RD2E21HB	TRIP	TRIP or pre-alarm 50% $I_{\Delta n}$	20...150 Vdc + 48 Vac



DELTA 96-F (NT746)

Flush mounted 96x96mm - manual reset - LED bar indicator $I_{\Delta n}\%$

Cat. Nos.	1st relay	2nd relay	Aux
RD2G213B	TRIP	TRIP or pre-alarm 50% $I_{\Delta n}$	230 Vac
RD2G21HB	TRIP	TRIP or pre-alarm 50% $I_{\Delta n}$	20...150 Vdc + 48 Vac

Accessories



DELTA TCS (NT817)

4 DIN modules - Monitor of switch release circuit with current launch coil, monitoring of 1 or 2 circuits that can be selected with voltage between 24...440 Vac/Vdc

Cat. Nos.	1st relay	2nd relay	Aux
RD2G213B	TRIP	TRIP or pre-alarm 50% $I_{\Delta n}$	230 Vac
RD2G21HB	TRIP	TRIP or pre-alarm 50% $I_{\Delta n}$	20...150 Vdc + 48 Vac



DEL (NT641)

Close-core ring current transformers

Cat. Nos.	Ø Hole	$I_{\Delta n}$ min*
TDGA2	28mm	0.03A
TDGB2	35mm	0.03A
TDGH2	60mm	0.03A
TDGC2	80mm	0.03A
TDGD2	110mm	0.1A
TDGE2	140mm	0.3A
TDGF2	210mm	0.3A

* $I_{\Delta n}$ minimum settable on the residual current relays with which the chosen ring current transformer will be combined



DEL A (NT641)

Open-core ring current transformers

Cat. Nos.	Ø Hole	$I_{\Delta n}$ min*
TDAA2	110mm	0.5A
TDAB2	150mm	0.5A
TDAC2	300mm	1A

* $I_{\Delta n}$ minimum settable on the residual current relays with which the chosen ring current transformer will be combined

DIGITAL INDICATORS





AC/DC lines 10A/500V, CT/VT direct connection or 50/400Hz in frequency

Multi-range digital indicators for connection on AC/DC networks direct up to 10Aac/dc - 500Vac/dc, from CT or from VT - frequency 50/400 Hz

Cat. Nos.	Technical note	Dimensions (mm)	Model	Program display	Aux
DG3P06P5	NT874	72x36x108	DGP 36 P2k	±1999 - measurement units as per Note 1	230 Vac
DG3P0MP5	NT874	72x36x108	DGP 36 P2k	±1999 - measurement units as per Note 1	20...60 Vac 20...150 Vdc
DG8P06P5	NT877	72x72x108	DGQ 72 P2k	±1999 - measurement units as per Note 1	230 Vac
DG8P0MP5	NT877	72x72x108	DGQ 72 P2k	±1999 - measurement units as per Note 1	20...60 Vac 20...150 Vdc
DG9P06P5	NT878	96x96x108	DGQ 96 P2k	±1999 - measurement units as per Note 1	230 Vac
DG9P0MP5	NT878	96x96x108	DGQ 96 P2k	±1999 - measurement units as per Note 1	20...60 Vac 20...150 Vdc

Note 1 - adhesive label with the following units A, V, °C, %, W, Hz, kW, MW, kg, bar, var, kvar, Mvar, RPM, m/min, rpm/min, kg/cm², m³/h, kA, kV, mA, mV, m, m/h.

Other engineering units on request.



DC field sensors mA/mV/V

Digital multi-range indicators for connection on transducers, shunts and field sensors from field signals 1/5/10/20/4...20mA - 50/60/75/100/150mV - 1/5/10V

Cat. Nos.	Technical note	Dimensions (mm)	Model	Program display	Aux
DG3P0NP1	NT850	72x36x108	DGP 36 P2k	±1999 - measurement units as per Note 1	80...270 Vac 100...300 Vdc
DG3P0MP1	NT850	72x36x108	DGP 36 P2k	±1999 - measurement units as per Note 1	20...60 Vac 20...150 Vdc
DG8P0NP1	NT852	72x72x108	DGQ 72 P2k	±1999 - measurement units as per Note 1	80...270 Vac 100...300 Vdc
DG8P0MP1	NT852	72x72x108	DGQ 72 P2k	±1999 - measurement units as per Note 1	20...60 Vac 20...150 Vdc
DG9P0NP1	NT853	96x96x108	DGQ 96 P2k	±1999 - measurement units as per Note 1	80...270 Vac 100...300 Vdc
DG9P0MP1	NT853	96x96x108	DGQ 96 P2k	±1999 - measurement units as per Note 1	20...60 Vac 20...150 Vdc

Note 1 - adhesive label with the following units A, V, °C, %, W, Hz, kW, MW, kg, bar, var, kvar, Mvar, RPM, m/min, rpm/min, kg/cm², m³/h, kA, kV, mA, mV, m, m/h.

Other engineering units on request.



AC/DC lines and DC field sensors

Digital multi-range indicators for connection on AC/DC lines or on transducers, shunts and field sensors

Cat. Nos.	Technical note	Dimensions (mm)	Model	Program display	Aux
DG4P06P2	NT530	96x48x103	DGP 96 P2k	±1999 - measurement units as per Note 1	80...270 Vac 100...300 Vdc
DG4P0HP2	NT530	96x48x103	DGP 96 P2k	±1999 - measurement units as per Note 1	20...60 Vac 20...150 Vdc
DG4Q06P2	NT550	96x48x103	DGP 96 P10k	1999 - measurement units as per Note 1	80...270 Vac 100...300 Vdc
DG4Q0HP2	NT550	96x48x103	DGP 96 P10k	1999 - measurement units as per Note 1	20...60 Vac 20...150 Vdc

Note 1 - adhesive label with the following units A, V, °C, %, W, Hz, kW, MW, kg, bar, var, kvar, Mvar, RPM, m/min, rpm/min, kg/cm², m³/h, kA, kV, mA, mV, m, m/h.

Other engineering units on request



AC lines

Digital multi-range indicators from CT or direct connection up to 500V

Cat. Nos.	Technical note	Dimensions (mm)	Model	Program display	Aux
DG4G06C1	NT533	96x48x103	DGP 96	999 - measurement units as per Note 2	80...270 Vac 100...300 Vdc
DG4G0HC1	NT533	96x48x103	DGP 96	999 - measurement units as per Note 2	20...60 Vac 20...150 Vdc

Other engineering units on request

Note 2 - adhesive label with the following units A, V, kA.

ANALOGUE INDICATORS



Ammeters (NT755)

Analog indicators on transformers /5A connection, with moving iron equipment,
Accuracy 1,5



Cat. Nos. RQ48E 48x48mm	Cat. Nos. RQ72E 72x72mm	Cat. Nos. RQ96E 96x96mm	CT ratio	Scale 0...In
AN12D <u>1</u> A500	AN22D <u>1</u> A500	AN32D <u>1</u> A500	5/5A	0...5A
AN125 <u>1</u> B100	AN225 <u>1</u> B100	AN325 <u>1</u> B100	10/5A	0...1A
AN125 <u>1</u> B150	AN225 <u>1</u> B150	AN325 <u>1</u> B150	15/5A	0...15A
AN125 <u>1</u> B200	AN225 <u>1</u> B200	AN325 <u>1</u> B200	20/5A	0...20A
AN125 <u>1</u> B250	AN225 <u>1</u> B250	AN325 <u>1</u> B250	25/5A	0...25A
AN125 <u>1</u> B300	AN225 <u>1</u> B300	AN325 <u>1</u> B300	30/5A	0...30A
AN125 <u>1</u> B400	AN225 <u>1</u> B400	AN325 <u>1</u> B400	40/5A	0...40A
AN125 <u>1</u> B500	AN225 <u>1</u> B500	AN325 <u>1</u> B500	50/5A	0...50A
AN125 <u>1</u> B600	AN225 <u>1</u> B600	AN325 <u>1</u> B600	60/5A	0...60A
AN125 <u>1</u> B750	AN225 <u>1</u> B750	AN325 <u>1</u> B750	75/5A	0...75A
AN125 <u>1</u> B800	AN225 <u>1</u> B800	AN325 <u>1</u> B800	80/5A	0...80A
AN125 <u>1</u> C100	AN225 <u>1</u> C100	AN325 <u>1</u> C100	100/5A	0...100A
AN125 <u>1</u> C120	AN225 <u>1</u> C120	AN325 <u>1</u> C120	120/5A	0...120A
AN125 <u>1</u> C125	AN225 <u>1</u> C125	AN325 <u>1</u> C125	125/5A	0...125A
AN125 <u>1</u> C150	AN225 <u>1</u> C150	AN325 <u>1</u> C150	150/5A	0...150A
AN125 <u>1</u> C160	AN225 <u>1</u> C160	AN325 <u>1</u> C160	160/5A	0...160A
AN125 <u>1</u> C200	AN225 <u>1</u> C200	AN325 <u>1</u> C200	200/5A	0...200A
AN125 <u>1</u> C250	AN225 <u>1</u> C250	AN325 <u>1</u> C250	250/5A	0...250A
AN125 <u>1</u> C300	AN225 <u>1</u> C300	AN325 <u>1</u> C300	300/5A	0...300A
AN125 <u>1</u> C400	AN225 <u>1</u> C400	AN325 <u>1</u> C400	400/5A	0...400A
AN125 <u>1</u> C500	AN225 <u>1</u> C500	AN325 <u>1</u> C500	500/5A	0...500A
AN125 <u>1</u> C600	AN225 <u>1</u> C600	AN325 <u>1</u> C600	600/5A	0...600A
AN125 <u>1</u> C800	AN225 <u>1</u> C800	AN325 <u>1</u> C800	800/5A	0...800A
AN125 <u>1</u> D100	AN225 <u>1</u> D100	AN325 <u>1</u> D100	1000/5A	0...1kA
AN125 <u>1</u> D120	AN225 <u>1</u> D120	AN325 <u>1</u> D120	1200/5A	0...1.2kA
AN125 <u>1</u> D125	AN225 <u>1</u> D125	AN325 <u>1</u> D125	1250/5A	0...1.25kA
AN125 <u>1</u> D150	AN225 <u>1</u> D150	AN325 <u>1</u> D150	1500/5A	0...1.5kA
AN125 <u>1</u> D160	AN225 <u>1</u> D160	AN325 <u>1</u> D160	1600/5A	0...1.6kA
AN125 <u>1</u> D200	AN225 <u>1</u> D200	AN325 <u>1</u> D200	2000/5A	0...2kA
AN125 <u>1</u> D250	AN225 <u>1</u> D250	AN325 <u>1</u> D250	2500/5A	0...2.5kA
AN125 <u>1</u> D300	AN225 <u>1</u> D300	AN325 <u>1</u> D300	3000/5A	0...3kA
AN125 <u>1</u> D400	AN225 <u>1</u> D400	AN325 <u>1</u> D400	4000/5A	0...4kA

In stock even in version with full scale value at the end 2In and 5In.

Cat. Nos. 2In: replace number underline with "2"

Cat. Nos. 5In: replace number underline with "5"

Voltmeters (NT759)

Direct connection analog indicators, with moving iron equipment,
Accuracy 1,5



Cat. Nos. RQ48E 48x48mm	Cat. Nos. RQ72E 72x72mm	Cat. Nos. RQ96E 96x96mm	Range	Scale
AN15DDC300	AN25DDC300	AN35DDC300	300V	0...300V
AN15DDC500	AN25DDC500	AN35DDC500	500V	0...500V

TRANSDUCERS



Transducers for alternating voltage and current

Compact transducers in 2 DIN module format, alternating voltage and current measurement with accuracy in class 0.5 EN60688 from 0% to 120% of the input value - selectable output by front dip switch 0...5/10/20mA - 4...20mA - 0...5/10V - 2...10V



TEMA I4 (NT554)

Current measurement of the average value, calibration placed in ratio with the TRMS Response time $\leq 300\text{ms}$

Cat. Nos.	Current	Aux	No. of Outputs
TM3I330	5A	230 Vac	1
TM3IH30	5A	20...150 Vdc + 48 Vac	1
TM3I310	1A	230 Vac	1
TM3IH0	1A	20...150 Vdc + 48 Vac	1



TEMA I4e (NT628)

Current measurement of the TRMS even in systems subject to considerable harmonic disturbances Response time $\leq 100\text{ms}$

Cat. Nos.	Current	Aux	No. of Outputs
TM4I330	5A	230 Vac	1
TM4IH30	5A	20...150 Vdc + 48 Vac	1
TM4I310	1A	230 Vac	1
TM4IH10	1A	20...150 Vdc + 48 Vac	1



TEMA U4 (NT555)

Voltage measurement of the average value, calibration placed in ratio to the TRMS Response time $\leq 300\text{ms}$

Cat. Nos.	Current	Aux	No. of Outputs
TM3U320	110V	230 Vac	1
TM3UH20	110V	20...150 Vdc + 48 Vac	1
TM3U390	400V	230 Vac	1
TM3UH90	400V	20...150 Vdc + 48 Vac	1



TEMA U4e (NT629)

Voltage measurement of the TRMS even in systems subject to considerable harmonic disturbances Response time $\leq 100\text{ms}$

Cat. Nos.	Current	Aux	No. of Outputs
TM4U320	110V	230 Vac	1
TM4UH20	110V	20...150 Vdc + 48 Vac	1
TM4U390	400V	230 Vac	1
TM4UH90	400V	20...150 Vdc + 48 Vac	1

Multimeasure transducers


Transducers that can be entirely configured on site, main electrical measurements taken with accuracy in class 0.5 EN60688 - response time $\leq 300\text{ms}$



TEMA fP (NT514)

Connection on LV/MV single phase and three phase line
True RMS of: kW, kvar, kVA, Hz, $\cos\phi$, h, phase angle
Programmable analogue output $\pm 5/10/20\text{mA}$ - $4...20\text{mA}$ - $\pm 10\text{V}$ - $1...5\text{V}$

Cat. Nos.	Current	Voltage	Aux	No. of Outputs
TM8P03120	5A	500V	230Vac	1
TM8P0H120	5A	500V	230Vac	1



TEMA Pr4 (NT848)

Connection on LV/MV single phase and three phase line
True RMS of: A, V, kW, kvar, kVA, Hz, $\cos\phi$, h
4 programmable analogue outputs $0...20\text{mA}$ - $4...20\text{mA}$

Cat. Nos.	Current	Voltage	Aux	No. of Outputs
TM960451	5A	80...690 V (F-F)	80...265 Vac + 110...300 Vdc	4
TM960452	5A	50...400 V (F-N)	11...60 Vdc	4

Accessories

ATM96002	Tema Pr4 programming kit
IF96005	Alarm module 2 relay outputs assignable to the measurements made by Tema Pr4

CT with built-in transducer

Current transformer with built-in transducer for measuring of alternating current (TT35 - TT35A) and direct current (HT35Bm) with accuracy in class 1 EN60688 - hole for passing cable 35mm in diameter.



TT35 (NT433)

2 wire technology for A.C. lines - Response time $\leq 500\text{ms}$

Cat. Nos.	Current	Aux	Output
TT1AA502A	5/10/15/20/25/30/35/40/45A	10...34 Vdc	4...20mA
TT1AB152A	15/30/45/60/75/90/105/120/135A	10...34 Vdc	4...20mA
TT1AB252A	25/50/75/100/125/150/175/200/225A	10...34 Vdc	4...20mA
TT1AB502A	50/100/150/200/250/300/350/400/450A	10...34 Vdc	4...20mA



TT35A (NT434)

4 wire technology for A.C. lines - Response time $\leq 500\text{ms}$

Cat. Nos.	Current	Aux	Output
TT1BA5023	5/10/15/20/25/30/35/40/45A	230 Vac	4...20mA
TT1BA2523	25/50/75/100/125/150/175/200/225A	20...150 Vdc + 48 Vac	4...20mA
TT1BA2533	25/50/75/100/125/150/175/200/225A	230 Vac	0...10V



HT35Bm (NT763)

4 wire technology for D.C. lines - Response time $\leq 300\text{ms}$

Cat. Nos.	Current	Aux	Output
HT1BM1027	10/20/30/40/50/60/70/80/90/100A	80...265 Vac + 110...300 Vdc	4...20mA
HT1BM102C	10/20/30/40/50/60/70/80/90/100A	20...60 Vdc + 24 Vac	4...20mA



Viale Borri, 231
21100 Varese - Italy
www.imeitaly.com

In accordance with its policy of continuous improvement, the Company reserves the right to change specifications and designs without notice. All illustrations, descriptions, dimensions and weights in this catalogue are for guidance and cannot be held binding on the Company